

EuroFit Fabric Hanging Banner Displays - 8' Triangle

Product Specifications

Parts list:

A: (12) Long Bars



(6) Right Side + (6) Left Side

B: (3) Short Bars

C: (3) Eye Bolts


D: (9) Short Screws

E: (3) Curved Side Support




Hanging Cables not included.


Most convention centers will require you to use their hanging hardware.



Connect (1) A-Left and (1) A-Right together to make a side of your triangle. Do this 6 times to construct the sides of your triangle. Set 3 aside for later use.




Align the ends of the each side as show, making sure the groves in each piece properly align.




Please note: A 60 degree angle should be formed.



Please Note: Button Locks should be facing inwards away from outside edge.




Using the short screws (D) attach the Short Bar (B) to each corner as pictured.




Attach the curved side supports (E) to the center of each side using a Short Screw (D), making sure the curved side support bows in towards the center of the square.




Set the assembled base on the ground so that the Short Bars are facing upward.




Attach the 2nd set of long bars (A) to the top of the curved side support bars (E) using the remaining shorts screws (D). Align the corners, but do




With the help of another person, position your graphic so the center seam is centered with the bottom frame and the corners are aligned. Raise the graphic up and over the outside of the frame.



Please Note: Align each of the re-enforced holes with the top of each short bar (B)



Align all holes, then insert Eye Bolts (C) and hand-tighten.



Once all long screws are in place, lift the inside of the graphic and zipper The sections together.

Hanging Cables not included.

Most convention centers will require you to use their hanging hardware.

Storage and Care

Place all product parts into Carry Case and store in a cool dry location. Machine wash the graphic on gentle cycle with a mild detergent. Tumble dry on low heat only. Do not dry-clean, do not iron.