
# Trilogy Banner Display

#### **Product Parts if Installing Banners**

- 1 Snap Banner Rail (x6)
- 2 Graphic Banner (x3)
- 3 Vertical Telescoping Pole (x3)
- 4 Corner Hinges (x6)






#### **Banner Install**

### Step 1

Begin by removing all parts from the case and place them on a clean, flat surface.

Attach all Snap Banner Rails (1) to the tops and bottoms of the graphics. To do this, first open the clamp of the Snap Banner Rail.



### Step 3


Continue the process in Step 2 to the top and bottom of all Graphic Banners (2). You should have 3 Graphic Banners

that look like this:

## Step 2


Fully insert the Graphic Banner (2) into the groove of the Snap Banner Rail (1). When in place push down on Snap Banner Rail (1) to close

into place.





To avoid creasing your graphic, DO NOT roll or store them with the Snap Banner Rails still attached.



# **Display Set up**

## Step 4


Assemble all Vertical Telescoping Poles(3)



# **Display Set-Up Continued...**

### Step 5

Insert the end connectors of the Vertical Telescoping
Poles (3) into the rear groove on the Snap Banner Rails
(1) where the "insert" sticker is located.



### Step 7

Take all Corner Hinges (4) and loosen all top screw knobs to accept the Snap Banner Rails (Do NOT take screws completely out of Hinge)



### Step 9

Repeat Step 8 on all 4 corners of ONE Graphic Banner with Snap Rails. **NOTE:** screw knobs on all Corner Hinges must face away from the Graphic Banner (they will face UP on the top Rail and DOWN on the bottom)




### Step 6

Adjust the Vertical Telescoping Poles (3) until the Graphic Banner is taut.

Repeat steps 5 and 6 to the other Graphic Banner with Snap Rails. You will have three total when complete.

### Step 8

Start with ONE Graphic Banner with Snap Rails that has the Vertical Telescoping Pole (3)




knob to secure.



### Step 10

You can now attach the other Graphic Banner with Snap Rails to the one that was created in Steps 8 and 9.





# **Storage and Care**

Place all product parts into Soft case (with a sturdy cardboard insert to protect product) and store in a cool dry location. To avoid creasing your graphic, DO NOT roll or store them with the Snap Banner Rails still attached.

To clean, wipe with damp cloth.

