


Crystal Edge Light Box

325050, 325051, 190298
325052, 325053, 190299

Product Parts

- 1 - Frame
- 2 - Bolts/Standoffs (x4)
- 3 - Hooks and Chain (x2)
- 4 - Cord
- 5 - AC Adaptor w/
On Off Switch
- 6 - Power Cord
- 7 - Large Standoffs (x2)



Sign Install and Setup

Step 1

Remove the Frame (1) from packaging and place on a clean surface. With the display facedown, remove the Bolts (2).




Step 2

Remove the back of the Frame (1). Place your graphic onto the front of the Frame (1) facedown. Replace the back of the frame and Bolts/Standoffs (2) to secure into place.



Step 3

Connect the Cord (4) to the Power Cord (6). Connect the Power Cord (6) to the AC Adaptor (5). Plug the Power Cord (6) into an outlet. Turn your display on or off by using the On Off Switch (5).



Step 4



Hang your Display:
Using Hooks and Chain (3).

-or-

Attach Standoffs (2) to wall.
(Standoff wall mounting hardware not included)

-or-

Attach Large Standoffs (7) to the bottom side of Frame (1) to use as legs.



Storage & Care

Place all product parts into Shipping Box and store in a cool dry location. To clean, wipe with damp cloth.

Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.