

Signicade Metropolitan

Product Parts

1 - Frame



KIT INCLUDES

2 - Single-Sided Graphics or
2 - Double-Sided Graphic

OPTIONAL GRAPHICS


- Double-Sided Rider Graphic
- Single-Sided Side Graphic
- Double-Sided Side Graphic



Banner/Sign Install OR Display Set-Up


Step 1

Remove the display from the box and place it on a clean flat surface. *If you purchased the optional rider, see **Step 1** in Installation for Optional Rider or Side Graphics.* Extend the hinged A-Frame until the unit stands on its own.



Step 2

Slide your first graphic into the recessed area of the display and under the two tabs located on the vertical edges. Allow the graphic to extend below the top edge of the recessed area until the top of the graphic fully enters the recessed area.



Step 3

Lift your graphic upwards until it fully passes into the open slot behind the top recessed edge of the display and the bottom edge of the graphic can easily enter into the lower bevelled slot.



Step 4

Once your graphic is secured rotate your display and repeat the previous steps to secure your second graphic and the Signicade Metropolitan is ready to display.



To add water or sand, simply pull the plug located on the one side of the display, fill, and replace plug.

Installation for Optional Rider or Side Graphics

Step 1

Center the Rider on the top of the unit between the handles. Extend the hinged A-Frame until the unit stands on its own.



Step 2

Slide the Side Graphics into the grooves on the side of the unit and slide the panel upwards until it is fully seated inside the side grooves of the unit. Repeat for other side.



Storage & Care

Store in a cool dry location. To clean, wipe with damp cloth.