


Scan to view Product Instructional Video or visit:  
[www.creativedisplaysite.com/RollUpLit.html](http://www.creativedisplaysite.com/RollUpLit.html)



## Product Parts

- 1 - Mesh Holder w/Rails
- 2 - Shock Cord Pole
- 3 - Foot
- 4 - Top End Caps
- 5 - Bottom End Caps
- 6 - Top Connector



## Display Set-Up

### Step 1

Remove parts from bag and place on clean surface. Slide the Top Connector (6) onto the back of the top Rail (1). Place the Top End Caps (4) onto the sides of the top Rail (1).



### Step 2

Slide the Foot (3) onto the back of the bottom Rail (1). Place the Bottom End Caps (5) onto the sides of the bottom Rail (1).



### Step 3

Assemble the Shock Cord Pole (2) and insert the Pole (2) into the receptacle on the Foot (3).



### Step 4

Lift the top rail up and gently bend the Pole (2) to connect the Top Connector (6) to the top of the Pole (2).



## Storage

Place all product parts into Carry Case and store in a cool dry location.



## Care

Spot clean with damp cloth.