# **Showstopper Umbrella**


#### **Product Parts** 1 - Base 2 - Post Support 3 - Ground Stakes (x4) 4 - Canopy 5 - Wing Bolt

6 - Wingnut 7 - Large Washer

8 - Lock Washer

9 - Frame

10 - Soft Case





## **Display Setup**

#### Step 1

Remove all parts from shipping box, and set on a clean flat surface. Verify you have the items listed above.

#### NOTE:

This Product is designed to be used with a standard patio table. Not included.

Remove the post support attachment from the Base (1). Screw in the Post Support (2).





## Step 3

Insert the Post Support (2) into the top of the Base (1). Flip Base (1) over. Put on Large Washer (7), Lock Washer (8) and then screw on the wingnut (6) to secure.







Step 4

Step 2


Swing open the four legs on the bottom of the Base (1).





## Step 5

Set the Base under Patio Table and Insert the Frame (9) throught the hole of the table and into the Support Post (2). Screw in the Wing Bolt (5) into the Frame (9) to secure.





## Step 6

Drape the Canopy (4) over the Frame (9) by centering the hole over the cap at top of the Frame (9). Insert the four arms of the Frame (9) into the four pockets on the ends of the Canopy (4).







## **Display Setup Continued**

#### Step 7

To open the Canopy (4), raise up on the height adjustment connector until it clicks into its locking position.



## Step 8

To raise the Canopy's (4) height, push in the lever on the height adjustment connector and push up until it clicks into one of the four locking positions.



### Step 9

Remove the cap on the Base (1). Fill with sand or water (if desired). Replace cap.





FORNO PIZZA

## **Disassembly**

#### Step 1

To lower Umbrella, press top lever on Frame (9). Press bottom lever on Frame (9) to lowest height. Remove Canopy (4).





## Step 2

Remove Wing Bolt (5) from Frame (9). Remove Frame (9) from Base (1).







## Step 3

Fold in feet on Base (1) and follow steps 2 & 3 on Display Setup in reverse order.



## **Storage & Care**

Place all Base (1) parts into Soft Carry Case (10). Fold Canopy (4) and place in plastic bag. Place Frame (9) inside Box.

Store in a cool dry location. To clean, wipe with damp cloth.