

Showgoer Case-to-Podium



Sel-Ok


Step 1


Unlatch and unpack all items from Hard Carry Case (1). Place on a clean flat surface.



Step 3

Unroll the Coroplast (2) and secure together. Slide each end into the channel grooves of the metal connector.






Step 5

Place the bottom of the Hard Case (A) into the top opening created by the coroplast (2). Make sure the Concave side is facing up. Tuck in the straps as you set it into place.



Step 2

Place the top of the Hard Case (B) (with convex side facing up) on the floor in the location you want to display your counter. This will become the base of your Showgoer Counter.




NOTE:

Parts A/B/3 all have the same tapered shape. For easy installation make sure they are all facing the same direction.



Step 4

Once Coroplast (2) is secured together into an oval shape, place it over the top of the Hard Case (B).



Step 6

Slide Fabric Graphic (4) over the unit you just created. Align seam to backside of Counter.



Set-Up Continued...

Step 7

Position Fabric Graphic (4) into place on Coroplast (2).

NOTE: approx 4" of the top portion will hang into the concave area of the case.



Step 8

Place the Counter Top (3) into position ensuring that


the Fabric Graphic (4) stays tucked into the Case.



Disassembly Instructions

Step 1

Remove Counter Top (3) and place off to the side. Remove the bottom of the Hard Case (A) that was being used as the Counter Top base and slip off Fabric Graphic (4)



Step 3

Secure top of the Hard Case (B) into place and latch the straps.



Storage and Care

All products get stored within the Hard Carry Case with Wheels. Store in a cool, dry place.


To clean hard case, wipe with damp cloth.

To clean fabric wrap, machine wash cold, gentle cycle. Tumble dry low.

Step 2

Remove Colroplast (2), roll and place into the bottom of the Hard Case (A). Fold up Fabric Graphic (4) and place into the

Case (A). Place Counter Top (3) over the parts to be stored.



Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.