



Canopy Ceiling

Product Parts


1 - Ceiling Graphic



Product Set-Up


Step 1

Pull up four corners of tent canopy. Attach ceiling graphic corner hook and loop above upper leg locks.




Step 3

Loosen or tighten straps to desired fit.



Step 2

Work your way around the frame attaching the side hook and loop around bottom truss bar pulling graphic taut.



Storage

Store in a cool, dry location.

Care

To clean, wipe with damp cloth.