
# **Eurofit Cascade**

#### **Product Parts**



- 2 3pc Right Pole
- 3 90° Top Back Corners (x2)
- 4 Curved Top Front Poles (x2)
- 5 Graphic
- 6 90° Bottom Corners
- 7 Top Back Center Pole
- 8 Horizontal Center Pole
- 9 Bottom Center Pole
- 10 Feet (x2)
- 11 Plastic Hinge Connector

## **Display Set-Up**

### Step 1

Begin by removing all parts from the carry case and place on a clean, flat surface. Ensure you have all the components listed above.

2

3 📼

### Step 2

10

4


80

Assemble all the poles by connecting the corresponding numbers together while pressing the snap button as shown.

# 12 12


## Step 4

Drape the Graphic (5) over the hardware until it reaches the feet (10).



#### illustrated in the image to the right.

Step 3



### **Plastic Hinge Connector**

Used to connect all Eurofit Displays with 1.25" Diameter Poles.



Place all product parts into Carry Case and store in a cool dry location. Recommended for indoor use only. Machine wash on gentle cycle using mild detergent. Tumble Dry No Heat. Do NOT dry clean, Do NOT Irón.