


Golf Cart Cuffs

Product Parts

- 1 - Foam Cuff (x2)
- 2 - Graphic (x2)



*cuffs come in two lengths: 11" & 16"




Product Set-Up

Step 1

Remove Foam Cuff (1) and Graphic (2) from the box. Open Foam Cuff (1) and place around the upright pole of the golf cart.




*If foam slides down when placed on upright pole, curl the inner diameter of the foam. Then stretch neoprene cuff over foam to cinch tightly against upright pole.



bird's eye view of cinched foam

Step 2

Wrap Graphic (2) over Foam Cuff (1) and secure with attached hook and loop (image a). Certain uprights may have too large of a circumference for the foam. In this case, install neoprene cuff directly around upright (image b).



WARNING! Golf Cart Cuffs may obstruct operator's view. Relocate cuff if it poses an operating hazard.

Storage

Store in a cool, dry location.

Care

To clean, wipe with damp cloth.