

Inflatable Couch

Product Parts

- 1 - Inflatable Chair (x3)
- 2 - Graphic
- 3 - Electric Blower (optional)
- 4 - Hand Pump (optional)

Note:
Inflatable Couch requires three inflatable chairs.



Display Set-Up

Step 1

Insert the Optional Blower or Pump's (3/4) hose into the intake valve of two (2) of the Inflatable Chairs (1) and begin to fully inflate.


*** DO NOT OVER INFLATE THE CHAIRS AS THIS MAY CAUSE DAMAGE.**



Step 3

Insert the deflated Inflatable Chair (1) in between the two Inflated Chairs (1).


Insert the Optional Blower or Pump's (3/4) hose into the intake valve of the Inflatable Chair (1) and begin to inflate until about 2/3 full. *** DO NOT FULLY INFLATE AT THIS TIME.**



Step 5


Adjust the seams of the Graphic (2) to align to the seams of the Inflatable Chair (1). Once aligned, continue to inflate until Graphic (2) is tight to the Inflatable Chairs (1).

*** DO NOT OVER INFLATE THE CHAIR AS THIS MAY CAUSE DAMAGE.**




Step 2

Slide one of the Inflated Chairs (1) into the opening of the Graphic (2) and slide the Inflatable Chair (1) all the way over to the right side of the Graphic (2) and align the seams of the Graphic (1) to the seams of the Chair (1). Repeat for the left side.




Step 4

Locate the clear pockets on the sides of the Inflatable Chairs (1) and align one chair to the other two chairs (as shown).



Step 6

Close the Intake Valves on the three Inflatable Chairs (1).



Step 7

Reach in between the chairs and pull the elastic straps toward the opening and attach to the corresponding button (as shown).

