

Sail Sign Tri-Post Base with Graphic Topper

Product Parts

- 1 - Base
- 2 - Tri-Post Hardware
- 3 - Hexagon Flat Head Bolt
- 4 - 5mm Hex Wrench
- 5 - Graphic Topper
(included in kit only)



Display Set-Up

Step 1

Carefully lift the Base (1) and insert the Hexagon Flat Head Bolt (3) into the hole from the underside.

Step 2

If a Graphic Topper (5) is being used, apply it to the base before attaching the 3 Post Hardware (2) to the bolt. Use the 5mm Hex Wrench (4) to secure the bolt to the 3 Post Hardware.

Step 3

Hoist your Sail Sign(s) onto the posts.

Only sail signs 13' and under are recommended for use with this base.

Sail Signs sold separately.



Storage & Care

Store in a cool, dry place. To clean, wipe with a damp cloth.