


Swing A-Frame

Product Parts

1. Side Section (x2)
2. Bottom Horizontal Bar (x2)
3. Top Horizontal Bar
4. Bolts (x6)
5. Hex Wrench (Metric 5)
6. Sign



Kit will come with Blank Chalkboard or Imprinted Sign




Display Set-up

Step 1

Begin by removing all parts from the box and place on a clean, flat surface. Ensure you have all the components listed above.

Step 2

Attach Bottom Horizontal Bars (2) to each Side Section (1) using bolts (4) and Hex Wrench (5) as shown in the diagram below.
DO NOT OVERTIGHTEN BOLTS



Step 3

Attach Top Horizontal Bar (3) to each Side Section (1) using Bolts (4) and Hex Wrench (5) as shown in the diagram below.
DO NOT OVERTIGHTEN BOLTS



Step 4

Attach Sign (6) by opening the clip on the Top Horizontal Bar (3) and hooking open end of the clip through the holes on the sign (6)



Storage & Care

Store in a cool dry location. To clean non-graphic hardware, wipe with a damp cloth.