


Trigga Go Apparel Bar

Product Parts


1. Top Pole (x2)
2. Bottom Pole (x2)
3. Apparel Bar (x2)
4. Double Pole Foot (x2)
5. Double Pole Top Bracket (x2)
6. Top Bracket Thumbscrew (x2)



Display Set-up

Step 1

Attach the Top Pole (1) to the Bottom Pole (2) by turning connector locks.



Step 2

Replace the foot on the chosen pole from your current TRIGA Go wall or U-booth with the Double Pole Foot (4).

Insert Bottom Pole (2) into the remaining space on the Double Pole Foot. Twist pole to secure.



Step 3

Attach the Double Pole Top Bracket (5) to the Top Crossbar on your wall or U-Booth using the turn and push knob.

Then align opening on the small end to the top of the Top Pole (1) and secure using the green Top Bracket Thumbscrew (6).



Step 4


Using the turn and push knob attach the Apparel Bar (3) onto the Pole at your preferred height.

Repeat for 2nd Apparel Bar.



How to use turn and push knobs

1. Insert the ridge into the track on the hardware with the knob parallel to the track
2. Turn knob so it is perpendicular to Track in the Hardware
3. Push to secure



Storage & Care

Place all product parts into Carry Case and store in a cool dry location. To clean non-graphic hardware, wipe with a damp cloth.