



77.5"W & 115"W Pop-Up Table & Fitted Throw

Product Parts

1. Table Frame
2. Table Top
3. Top Rails
 - 3a. 77.5" (x8)
 - 3b. 115" (x12)
4. Fitted Throw



Display Set-up

Step 1

Assemble Top Rails (3), sliding each section into one another till push button is locked.



Step 2

Expand Table Frame (1) by pulling on either side until fully expanded.

Adjust the height of the Table Frame (1) using the red levers on each leg.

- For 32"H Fitted Throw use 2nd hole position.
- For 38.5"H Fitted Throw use 4th hole position.

Expanding table may require 2 or more people.



Step 3

Attach Top Rails (3) to Table Frame (1) by sliding the ends onto the screws on front and back of table.



Step 5

Place Table Throw (4) over finished table.



Step 4

Roll the Table Top (2) out on top of table Top Rails (3).



Storage & Care

Place all product parts into Carry Case and store in a cool dry location. To clean non-graphic hardware, wipe with a damp cloth. Table Throw: Machine wash on gentle cycle using mild detergent. Tumble Dry on low heat setting. DO NOT iron or dry clean.